

# Instructions for Smart Curtain Light

## Product Parameters

Product Name	Smart Curtain Light
Product Model	DN-24V-98C14LX7
Width	70CM
Height	140CM
Input Voltage	100V-240V~ 50/60Hz
Working Voltage	24V
Product Power	8.4W
IP Rank	IP20
Application	Indoor use only
LED Bulbs	98
Wi-Fi Standard Required	2.4G Wi-Fi 802.11B/G/N WPA/WPA2

## Installation

- 1) Open the package and take out the light set.
- 2) check every component before installation to make sure the power supply meets the requirements of working voltage.
- 3) Install the curtain light on the desired position.

## Control the light

You can control this Wi-Fi enabled light set with your mobile phone with 2 options:

- 1) Enter the following URL on your mobile phone:  
<https://smart.jsopec.com/>
- 2) Scan the following QR CODE with appropriate APP :



Please check the following web page for detail information of Wi-Fi connection setup:  
<https://smart.jsopec.com/docs/connect>

## Main Functions

- \* 20 Preset modes
- \* Doodling
- \* Breathing flash with user specified color or auto changed colors
- \* 6H/18H Timer
- \* Many more functionalities will be added to the list, please keep updated.

## Safety Instructions

- 1) The curtain light cannot be plugged in the socket directly, the power adapter provided by the supplier is required.
- 2) The curtain light cannot be soldered to another one.
- 3) After opening the package, the adapter is allowed to connect and switching on power supply.
- 4) The LED bulbs are not replaceable, it is strictly forbidden to replace the light bulb.
- 5) This product is only for decoration, not for children's toys. Please keep children who are under 6 years old away from this product.
- 6) Please turn off the power supply when not in use for a long time, and do not expose it in the harsh environment.
- 7) Please do not disassemble the product, including the shell, adapter and controller.